

# Sevierville Events Center

## UTILITY SERVICES

*Multi-Purpose rooms have 1 120v receptacle in each floorbox*

### **Service Hall/Multi-Purpose**

- 208/120 volt 3 phase @ 225 amps
- Floorbox contains a 1-120 volt receptacle @ 16 amps max ( to prevent tripping breaker)

### **Exhibit Hall “A”**

- Can use above, 208/120 volt 3 phase @225 amps from service hall for North side
- At back of Hall, 208/120 volt 3 phase @ 400 amps
- Floorbox contains a 208/120 volt @ 60 amps max (combined usages)  
(The 120 volt devices are under the 60 amps 3 phase)

### **Exhibit Hall “B”**

- At back center of building, 208/120 volt 3 phase @ 400 amps
- At back South corner of building, 208/120 volt 3 phase @ 250 amps
- Floorbox contains a 208/120 volt @ 60 amps max (combined usage)  
(The 120 volt devices are under the 60 amp 3 phase)

### **Outdoor**

- At South West corner of building outside, 480/277 volt 3 phase @ 600 amp
- 20 amp, 120V quad receptacles and voice data outlets spaced 30' on center